



## Document Camera

## WVN Studio Guide

The document camera, or *visualiser*, is used to display documents and objects both at your end of the conference and at the remote end(s).

The camera is full colour and it can also be used to display transparencies or X-ray photographs.

When not in use, the document camera remains in standby mode. It is automatically switched on and off as part of the studio startup and shutdown procedures. The document camera is controlled entirely from the studio touch screen controller.




Press this button to switch on the **Lower Lamp**. Use this setting for transparencies or x-rays. It may take several seconds for the light to illuminate.

To activate the main **Upper Lamps** on the camera, press this button. Use this setting for normal paper documents or objects.

If you prefer not to artificially illuminate the document, press the **All lamps Off** button.

Use this button to zoom in on the picture. Keep the button pressed to zoom in quickly.



Use the **Auto Focus** button to reactivate the auto focus feature if you have used the manual focus

Use this button to zoom out on the picture. Keep the button pressed to zoom out quickly.

The manual focus buttons are used to override the auto-focus function. Use the **Focus In** or **Focus Out** buttons to focus the object on the camera. In normal use the auto-focus function operates adequately.

To return to the main control screen when you have finished controlling the document camera press the **Back** or the **Home** button.