




Connecting a Laptop

WVN Studio Guide

It is possible to connect a laptop or other VGA device that will allow you to send the pictures from that device to the far end of the conference.

The data PC is provided within the studio for this purpose, however we acknowledge that on occasions you may prefer the flexibility of connecting another device.

The pictures from the laptop connection are sent via the videoconferencing connection. Because of this, we would normally recommend that you use the data PC for data and application sharing whenever possible.



The laptop is connected to the system using a standard VGA monitor cable. Connect the laptop monitor cable to the **RGB1** port on the **INPUT** section at the back of the document camera (see the picture opposite – the laptop connection is highlighted). A cable is provided in your studio for convenience and may already be connected to the document camera.



It is also possible to play sound from the laptop both in your studio and in the studios at the far end of the conference. To do this, connect the speaker connection on the laptop sound card to the audio connection on the imageshare device (see opposite), using the cable provided in your studio.



Home	Call	Cancel	Full Screen	Help	Exit
24:00 Source					
Mute mic	Camera 1	Camera 2	Document Camera	SEND	
Projector	DVD/VCR	AUX	Laptop	PREVIEW	
Volume Control				CONTROL	

To preview the laptop picture, press the **Laptop** button followed by **Preview**. The laptop picture will appear on the preview screen after a short delay. To send the laptop picture to the far end of the conference, press the **Laptop** button followed by **Send**.

Please note that it is not possible to preview the document camera whilst sending the laptop picture or vice-versa. The table below shows the laptop screen configuration that is supported by the system:

Screen resolution	Refresh rate
640 x 480	60 Hz, 72 Hz, 75 Hz
800 x 600	56 Hz, 60 Hz, 72 Hz, 75 Hz
1024 x 768	60 Hz, 70 Hz, 75 Hz

If the laptop is configured in accordance with the table shown opposite but you are unable to send or preview the laptop picture, check that the laptop is outputting a picture from its monitor port (VGA). Laptops do not always do this by default but this can normally be enabled using a function key on the keyboard.